



Tipp-Ex®

Los Esenciales



49331
Cinta Correctora Tipp-Ex® Easy Correct,
longitud 12 m



24466
Cinta Correctora Tipp-Ex® Mini Pocket Mouse®,
longitud 6 m



44329
Cinta Correctora Tipp-Ex® Micro Tape Twist,
longitud 8 m



52739
Cinta Correctora Tipp-Ex® Soft Grip,
longitud 10 m



18636
Cinta Correctora Tipp-Ex® Pocket Mouse,
longitud 10 m



2485
Frasco Corrector Tipp-Ex® Easy Correct, 20 ml



36239
Mini Corrector Lápiz Tipp-Ex® Mini Shake'n Squeeze, contenido 4 ml



26992
Corrector Lápiz Tipp-Ex® Mini Shake'n Squeeze, contenido 8 ml



Tipp-Ex®
Shake'n Squeeze

3 086126100685